



**85-0600**

**HOLLEY 1050/1150 CFM  
DOMINATOR STUBSTACK**

**This stubstack is designed to be used on Holley 1050 and 1150 CFM Dominator carburetors. The stubstack can hold down the baseplate of a cold air scoop, but will not work with any K&N Custom Chrome Racing Air Cleaners.**

**The design straightens the airflow and helps even out the flow to all four venturies. The design also decreases the restriction around the throttle bores.**

**DO NOT OVERTIGHTEN CENTER BOLT! Use loctite on the bolt or a nylon locking nut and a stud to ensure that it stays tight.**