

20075

99-02 CHEVY
SILVERADO
BILLET INSERT



20075

99-02 CHEVY
SILVERADO
BILLET INSERT

99-02 Chevy Silverado; 00-04 Chevy Suburban & Tahoe

Tools Required:

Die Grinder or Hacksaw
Phillips Screwdriver
File or Sand Paper

Hardware Provided / Parts:

1 - Upper Billet Insert (7 bars)
1 - Lower Billet Insert (7 bars)
8 - #8 x 3/4 Phillips Screws
8 - #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1.

Pop the hood. Remove the black cover over the radiator and remove grille shell from vehicle.

Step 2.

Lay the grille shell on its face. Using a die grinder or hacksaw, cut out the chrome upper and lower sections of the grille work. Cut close to the point where the grilles are molded to the main grille. File or sand any rough edges smooth.

Step 3.

Turn the grille shell over. Identify the upper and lower billet pieces. Lay each piece into the openings. Align the billets as desired, mark and drill the brackets on each billet. Fasten to the grille shell using the hardware provided.

Step 4.

Re-fit the complete grille assembly onto the vehicle. Reinstall the black radiator cover. Installation complete. *Thank you for purchasing your T-Rex billet grille.*