



Description: Projector Headlight
Part Number: 111190 - 111189

Application: 1999-2002 Chevrolet Silverado (1500-2500-3500)



Tools Needed:
4 Wire Splicer
Electrical Tape



Step 1: remove the two pins holding the headlight housing in place.



Step 2: remove the headlight.



Step 3: remove the headlight connectors for the high and low beam.



Step 4: take off the turn signals so we can splice the wires to the turn signals and halo resistor.



Step 5: Splice the black(-) and blue(+) parking light to the Anzo headlight. Green (+) wire to blue and black(-) to black.



Step 6: Splice the brown(+) wire to one red (+) wire from the new headlight, then black (-) to the other red wire.



Step 7: Connect the headlight plugs into the new headlight.



Step 8: Connect the resistor pack to the headlight halo.



Step 9: Plug and twist the turn signal light into the new headlight



Step 10: Put the headlight back into the housing and use the pins to lock in the headlight.



AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.