



Installation Guide for RECON part number 264245 series Ford Superduty Mirror Lights 2017-2019

Installation of this part can be completed with the mirrors installed on the truck. For the simplicity of this guide we have the mirror removed from the vehicle.

-You will need a small flat head screwdriver or hook pick, and a 7mm socket for this install-

1. Using your pick hook or screwdriver, remove the top and bottom glass portions of the mirror assembly by pressing on the retention tabs on the back side of the mirrors.



2. Carefully unplug the blind spot sensor and defroster plugs that are attached to the mirror glass.
3. Using the 7mm socket, remove the 5 bolts that are now exposed.



4. Using your hook pick or screwdriver, remove the puddle lamp from the bottom of the mirror assembly.



5. Next, release the three clips on the top of the mirror assembly and pry the two arms to separate the trim and gain access to the light assembly.





6. You will now have access to the light. Remove it from the assembly and install the RECON light in its place and reassemble the mirror housing.

Enjoy your new RECON mirror lights!!