



RECON Truck 264272BKCS Install Guide

Thank you for purchasing RECON projector headlights. These headlights offer a white DRL and switchback amber scanning turn signal. To access these functions you will need to connect the white wire to either your parking light positive or any accessory hot wire(for true DRL function). The yellow wire will need to be connected to your turn signal positive and the black wire to the ground. We highly recommend using a white, high powered LED parking/turn signal bulb to replace your OEM bulb as well.

If you have any further questions, please feel free to call or email us. www.gorecon.com

877.377.3266