

- 1** HOLD THE HOOD PROTECTOR IN PLACE AND FAMILIARIZE YOURSELF WITH THE FIT. LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2** REMOVE THE RUBBER SEALS FROM THE HOOD.
- 3** LINE UP THE HOOD PROTECTOR ON THE UNDERSIDE OF THE HOOD. INSERT THE SCREWS THROUGH THE , THE HOOD PROTECTOR AND INTO THE HOLES IN THE HOOD. **TIGHTEN JUST ENOUGH TO HOLD HOOD PROTECTOR IN PLACE.**
- 4** CENTER THE HOOD PROTECTOR ON THE HOOD AND THEN TIGHTEN THE SCREWS WITH SCREWDRIVER UNTIL SNUG. **DO NOT OVER TIGHTEN** THIS MAY DAMAGE YOUR NEW HOOD PROTECTOR.
- 5** CLOSE THE HOOD **CAREFULLY** TO CHECK THE FIT. IF THE HOOD PROTECTOR IS NOT CENTERED, SLIGHTLY LOOSEN THE SCREWS AND MOVE IT TO ONE SIDE OR THE OTHER UNTIL CENTERED AND RE-TIGHTEN THE SCREWS.

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

KIT CONTAINS:
HOOD PROTECTOR
6 MOUNTING SCREWS
6 WASHERS
TOOLS NEEDED:
PHILLPS SCREWDRIVER

