

KIT CONTAINS:

HOOD PROTECTOR

4 PLASTIC MOUNTING CLIPS

- 1** CENTER THE HOOD PROTECTOR WITH THE GRILLE.
- 2** INSERT THE PLASTIC CLIPS THROUGH THE HOLES IN THE HOOD PROTECTOR AND INTO THE 4 EXISTING HOLES LOCATED ON THE UNDERSIDE OF THE GRILLE.

FENDER SECTION INSTALLATION INSTRUCTIONS

KIT CONTAINS:

2 HOOD PROTECTOR (FENDER SECTIONS)

ALCOHOL PAD

TOOLS NEEDED:

PHILLIPS SCREWDRIVER

- 1** Raise the hood of the vehicle. On each fender there is a black rubber seal held on by three plastic clips. Using a phillips screwdriver, remove the center of each clip and remove the clips from the seals.
- 2** Hold the fender protector up to the fender and take note where the adhesive will make contact. Clean the area with the alcohol pad provided.
- 3** Remove the red liner from the tape. Slide the fender protector **behind** the rubber seal and reinstall the plastic clips through the seal, the fender protector and into the fender.
- 4** Carefully slide the taped edge of the fender protector between the fender and headlight. Line up the taped edge on the protector with the leading edge of the fender, and apply upward pressure on the protector to secure the adhesive in place.

CLEANING YOUR HOOD PROTECTOR: USE ONLY WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR!