



# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

**PACKAGE CONTENTS:** 1 Hood Protector 2 Mounting Screws 2 Plastic Washers

1. LIFT THE HOOD. REMOVE NUTS AND BOLTS CONNECTING HOOD AND GRILLE. CAREFULLY REMOVE THE GRILLE AND SET OFF TO THE SIDE WHERE IT WON'T GET DAMAGED.
2. PUT HOOD PROTECTOR INTO PLACE. INSERT THE MOUNTING SCREWS THROUGH THE SLOTS IN THE HOOD PROTECTOR AND INTO THE EXISTING HOLES IN THE HOOD. CENTER THE HOOD PROTECTOR ON THE HOOD, THEN TIGHTEN THE SCREWS WITH SCREWDRIVER UNTIL SNUG. **DO NOT OVER TIGHTEN** THIS MAY DAMAGE THE HOOD PROTECTOR.
3. REMOUNT GRILLE TO THE HOOD, SANDWICHING THE HOOD PROTECTOR BETWEEN THE HOOD AND THE GRILLE.
4. **CAREFULLY** CLOSE THE HOOD AND CHECK THE FIT. LOOSEN HARDWARE AND READJUST IF NEEDED.
5. CLEANING YOUR HOOD PROTECTOR - USE WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS.

