



**PART #4148
SINGLE SWING PEDAL
PART #4149
DUAL SWING PEDAL**

INSTALLATION INFORMATION

For single swing pedal #4148, the following master cylinders are suggested:

EIS # E-36862 or Wagner # F-36852
EIS # E-39626 or Wagner # F-39626
EIS # E-39967
EIS # E-44485 or Wagner # F-49220
EIS # E-32900 or Wagner # F-32900
EIS # E-32913 or Wagner # F-43426
EIS # E-44471 or Wagner # F-49221
EIS # E-44487 or Wagner # F-49202
EIS # E-32714
EIS # E-37073 or Wagner # F-37073
EIS # E-37072 or Wagner # F-35417

Note: In all cases, you must purchase a suitable clevis-type pushrod.

Caution: The wheel cylinder bore size should be the same or less than the brake master cylinder bore size.

For dual swing pedal #4149, the following master cylinders are suggested:

Bendix #11357	Brake 1"	Bore - Clutch 1"	Bore
Bendix #11201	Brake 1 1/8"	Bore - Clutch 1 1/8"	Bore
Bendix #11358	Brake 1 1/8"	Bore - Clutch 1"	Bore
Bendix #11205	Brake 1 1/4"	Bore - Clutch 1 1/8"	Bore
Bendix #11317	Brake 1 1/4"	Bore - Clutch 1 1/8"	Bore
Bendix #11309	Brake 1 1/2"	Bore - Clutch 1 1/8"	Bore
Bendix #11455	Brake 1 3/4"	Bore - Clutch 1 1/8"	Bore

Note: In all cases, you must purchase a suitable clevis-type pushrod.

Caution: The wheel cylinder bore size should be the same or less than the brake cylinder bore size.

For dual swing pedal #4149, the following slave cylinders are suggested:

Bendix #11792 3/4" Bore
Bendix #11791 3/4" Bore
Bendix #11806 3/4" Bore
Bendix #11807 3/4" Bore
Bendix #11845 3/4" Bore
Bendix #11888 3/4" Bore
Bendix #11882 5/8" Bore
Bendix #11915 1" Bore
Bendix #11916 1" Bore

For more specific information about which of these master cylinders or slave cylinders best suits your vehicle, refer to the respective EIS, Wagner or Bendix application catalog.

12438 Putnam Street • Whittier, CA 90602 tel (562) 921-0404 • fax (562) 921-7515
website: www.tdperformance.com • email: techsupport@tdperformance.com

4148-4149-instructionSheet-012607.cdr