

INSTALLATION INSTRUCTIONS

THIS KIT CONTAINS

1 - Left Motor Mount	4 - 7/16" Flat Washers
1 - Right Motor Mount	4 - 7/16"-14 x 1 1/4" Grade 8 Hex Head Bolts
1 - Left Frame Mount	2 - 9/16" Nylon Locking Nuts
1 - Right Frame Mount	2 - 9/16" Flat Washers
4 - Urethane Mount Bushings	2 - 9/16"-12 x 4 1/4" Grade 8 Hex Head Bolts
2 - Steel Bushing Mount Tubes	6 - 3/8"-16 x 1" Grade 8 Hex Head Bolts
4 - 7/16" Nylon Locking Nuts	6 - 3/8" Lock Washers

Installation Hints

Be sure to use the following Trans-Dapt Components for a trouble free install.

- Toyota P/S pump to Small block Chevy Adapter Bracket 79-80 #4570 & 81-95 #4571
- Toyota Crossmember extension #4573
- Toyota Transfer Case Shims #4569
- Small Block Chevy Motor Mount Shims #4125
- Trans Dapt Engine Tilter #9099
- Trans Dapt Remote Oil Filtration System #1122 or #1222 See catalog
- For added performance check out our full line of Carb. & TBI spacers & Adapters.

