



## Floor Liner Installation Instructions

Congratulations for purchasing the Sure-Fit Floor Liner. The best fitting floor liner on the market. These have been designed specifically to fit your vehicle. To insure the correct fit it is necessary to remove your vehicles factory floor mats before installing the Sure-Fit floor liner.

- 1- Remove factory floor mats.
- 2- Place Sure-Fit floor liner into place.
- 3- If your vehicle has retention hooks, be sure they are installed into the provided holes.
- 4- Many Sure-Fit Floor Liners come with Velcro pre-applied on the back to insure they will not slip. Ascertain where the Velcro will adhere. Clean the contact area, and adhere.



Driver's side



Passenger's side

**CLEANING INSTRUCTIONS:** Wash with warm water and a mild soap solution, using a soft, clean cloth or sponge. Avoid any oil based product that is designed to bring out a shine, as they will make the Sure-Fit Floor Liners slippery.

[www.westinautomotive.com](http://www.westinautomotive.com)

[www.wadeauto.com](http://www.wadeauto.com)