## This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger® seals properly.

## INSTALLATION

- 1. Remove the stock air filter.
- Install the appropriate velocity ring. See the figure below for the proper velocity ring location.
  Small diameter velocity ring: To be used on a stock motorcycle.
  Large diameter velocity ring: To be used for increased air flow on a motorcycle that has a carburetor recalibration kit installed.

## CAUTION: DO NOT REMOVE THE VELOCITY RING COMPLETELY OR DAMAGE TO THE ENGINE COULD RESULT.

- 3. Apply the provided gasket to the bottom of the filter plate.
- 4. Install the K&N Filtercharger® onto the filter plate and tighten the clamp.
- Install the entire assembly into the air box.
  Note: It may be helpful to put the stock screws into the filter plate and install the provided washers onto the stock screws before installing the assembly.
- Tighten the four stock screws evenly until they bottom out on the washers.
  CAUTION: The plate may warp and cause a loss of seal if the washers are not used properly.

## THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.

