



INSTALLATION INSTRUCTIONS

Part Number: HD-1717

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

* FREE K&N® decal To register your warranty, please see us online at knfilters.com/register. FREE K&N® decal *

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger® seals properly.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

INSTALLATION:

1. Disconnect the breather hose from the two breather bolts. (Fig. 1)
2. Remove the stock air filter from the air box.
3. Remove the breather hose from the stock air filter. (Fig. 2)
NOTE: The K&N® air filter will utilize the OE breather hose. (Fig. 3)
4. Clean all the sealing surfaces in the air box.
5. Install the OE breather hose to the K&N® air filter. (Fig. 4)
6. Install the K&N® air filter into the air box. **NOTE: Recommended torque for the K&N® filter is 45in-lbs.**
7. Connect the breather hose to the two breather bolts. (Fig. 5 & 6)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5



Fig. 6